




Mr Handsfree Car-Kit pro (1,99 EUR)



Locatie **Utrecht**
<https://www.advertentienx.nl/x-1001785-z>

Compatibility list CARKIT PRO
 ALCATEL C2891: OT CLUB db/ OT CLUB + db/ OT EASY db/ OT GUM db/ OT MAX db/ OT VIEW db/ Swing 200
 C2990: OT 300/ OT 301/ OT 302/ OT 303/ OT 304
 C3003: OT 500/ OT 501/ OT 700 /OT 701
 C4710: OT 310/ OT 311/ OT 331/ OT 332/ OT 511/ OT 512/ OT 515/ OT 525/ OT 535/ OT 715/ OT E205
 ERICSSON
 SONY ERICSSON
 IMATE C4406*: Jam/ PDA2K/ SP/ SP2/ SP3/ SP3i
 LG C3997: LG-510W/ LG-G3000/ LG-G3100/ LG-G5200/ LG-G5300/ LG-G5400/ LG-G7100/ LG-G7120/ LG-W3000/ LG-W5200/ LG-W5300
 C4529: A7150/ B2050/ B2100/ B2250/ C1150/ C2100/ C2200/ C3100/ C3320/ C3380/ C3400/ F2200/ F2300/ F2400/ F2410/ G1600/ G1610/ G5600/ KG110/ KP200/ U8120/ U8120i
 MITSUBISHI C3102: COSMO/ COSMO@/ GEO/ GEO@
 TRIUM C8760: M21i
 MOTOROLA C2938: V3688/ V3690/ V50/ V51/ V8080/ V8088
 C2983: C205/ C250/ C332/ C333/ C350/ C390/ C550/ T180/ T192/ T2288/ V150/ V2288
 C3010: Timeport 250
 C3126: Timeport L7089/ Timeport P7389

 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro	 https://www.advertentienx.nl/x-1001785-z Mr Handsfree Car-Kit pro
---	--	--	--	---	--	--	--	--	--

NOKIA C2822: 1610/ 1611
C2839: 3210/ 8210/ 8250/ 8850/ 8890
C2846: 5110/ 5120/ 6110/ 6150/ 7110
C3362: 6210/ 6310/ 6310i
C4000: 1100/ 1101/ 1110/ 1600/ 2100/ 2112/ 2300/ 2310/ 2600/ 2610/ 2626/ 2650/ 2652/ 3310/ 3330/
3410/3510/ 3510i/ 3650/ 3660/ 5210/ 5510/
6030/ 6060/ 6510/ 6600/ 7280/ 7380/8310/ 8800/ 8910/ 8910i
C4369*: 7650/ N-Gage
C4475: 6670/ 7610
C4611: 3100/ 3105/ 3120/ 3200/ 3220/ 3230/ 3250/ 3300/ 5070/ 5100/ 5140/ 5140i/ 5500Sport/ 6020/
6021/ 6070/ 6080/ 6085/ 6086/ 6100/ 6101/ 6102/ 6103/
6111/ 6131/ 6151/ 6170/ 6220/ 6225/ 6230/ 6230i/ 6233/ 6234/ 6260/ 6270/ 6288/ 6610/ 6610i/ 6680/
6681/ 6800/ 6810/ 6820/ 6822/ 7210/ 7250/ 7250i/
7260/ 7270/ 7360/ 7370/ 7373/ 7710/ 9300/ 9300i/ 9500/ E50/ E60/ E61/ E65/ E70/ N70/ N71/ N73/ N80/
N90/ N92
C8909: 1200/ 1650/ 1661/ 1662/ 1680c/ 2330c/ 2600c/ 2630/ 2760/ 2680 slide/ 3109c/ 3110c/ 3120c/
3500/ 3500c/ 3550/ 3600 slide/ 3720c/ 5000/ 5200/ 5610/ 6120c/ 6121c/
6220c/ 6267/ 6300/ 6500 slide/ 6555/ 7070 Prism/ 7100 Supernova/ 7210 Supernova/ 7310 Supernova/
7390/ 7500 Prism/ 7610 Supernova/ E51/ E66/ E71/ E90 Communicator/ N97
C8923: 2730/ 5220/ 5310/ 5630/ 6303c/ 6303i/ 6720c/ E72/ E75/ N76/ N78/ N79/ N81 8GB/ N81-3/ N82/
N82-1/ N95/ N96
ORANGE C4406*: SPV/ SPV-E100/ SPV C500/ SPV M500/ SPV M2000
PALM C4536: Treo 650
PANASONIC C2853: GD 30/ GD 50/ GD 70/ GD 90
C2907: GD 52/ GD 75/ GD 87/ GD 92/ GD 93/ GD 95
C3348: GD 35
C4376*: GD 67
C8791: A100/ A101/ A102/ A210/ G 50/ GD 55
C8913: X60/ X70/ X200/ X400/ X700/ X701
PHILIPS C3041: Ozeo/ SAVVY db/ SAVVY Vogue
C3171: 330/ Azalis/ Fisio 120/ 620/ 625/ 820/ 822/ 825/ Xenium 929/ 939/ 989/ 9@9/ 9@9++
QTEK C4406*: 7070/ 8010/ 8310/ S100/ S110
SAGEM C2860: 7-series/ 8-series
C3225: MC 912/ 920/ 932/ 936/ 939/ 940/ 950/ 959/ 959R/ MV 3000 serie/ MW 3000 serie/ MY-G5/ MY-
V55/ MY-V56/ MY-V65/
MY-X1 series/ MY-X2 series/ MY-X3/ MYX3-2/ MY-X3d/ MY-X4/ MY-X5/ MY-X5-2/ MY-X5m/ MY-X6 / MY-
X7
C4543: MY C2-3/ MY C3-2/ MY C4-2/ MY C5-2/ MY C5-2V/ MY Z5/ MY 302X
SAMSUNG C3065*: GH-2100/ SGH-N100/ SGH-N110
C3218*: A300/ A400/ E810/ S300/ S300m/ X120/ X500

C3232*: N400/ R200/ R210
C3935*: A800/ E100/ E400/ E700/ S100/ S500/ T500/ V200/ X450
C4338: N500/ N600/ N620/ T100/ T400
C4451: D100/ D410
C4468: E600
C4499: C200/ C200N/ C230F/ E330/ E330E/ E330N/ E710/ P510/ X460/ X461/ X490/ X640
C4512: C230/ D500/ D500E/ D600/ E300/ E310/ E340/ E350/ E350E/ E360/ E380/ E610/ E630/ E720/
E730/ E760/ E770/ E800/ E820/ E860V/ S400i/
X620/ X660/ X660V/ X700
C4581: C120/ C130/ C300/ X140/ X160/ X200/ X480/ X481
C4598: D800/ D820/ D830/ D900/ D900i/ E500/ E590/ E740/ E840/ E870/ E900/ F500/ U100/ U600/
X820/ X830/ Z400v/ Z510
C4635: D720/ E620/ E720/ S410i/ Z500/ Z500V/ ZM60/ZV30
C8814*: C100
C8852: P100/ P400/ X100/ X600
SHARP C4345*: GX1/ GX10/ GX15/ GX20 (Vodafone LIVE!)
C4482: GX25/ GX30
BENQ C3027: A35/ A36/ C25/ C25 power/ C28/ C35/ C35i/ M35/ M35i/ S25/ S35
SIEMENS C3096: S40
C3133: A40/ SL42/ SL45/ SL45i
C3966: A50/ C45/ C45i/ ME45/ ME45i/ M50/ MT50/ S45/S45i
C4314: A55/ A57/ A65/ C55/ CF62/ M55/ S55/ SL55
C4437: C65/ C72/ C75/ C65V/ CFX65/ CT65/ CV65/ CX65/ CX65V/ CX70/ CX70 Emoty/ CX70V/ CX75/
CXT65/ CXV65/ M65/ S65/ SL65/ ST65/ SP65/ SX1
C4444: ST55/ ST60
C4628: A31/ AF51/ E71/ EL71/ M81/ S68
C4673: AL21/ AX72/ CF110/ CL75/ S75
C8777*: CL50/ SL50
C8838: A51/ A52/ A60/ A62/ A75/ AX75/ C60/ CF75/ MC60/ M75/ SF65/ SK65
C8906: C62
SONY C3072: CMD-J5/ CMD-J6/ CMD-J7/ CMD-J70/ CMD-Z7
C3089: CMD-MZ5/ CMD-Z5
T-MOBILE C4406*: MDA Compact/ SDA
TOSHIBA C8784: TS21i
VODAFONE C4406*: VPA Compact
C2815: 628/ 688/ 768/ 788/ 868/ 888/ A1018s/ T10s/ T18s
C2969: R250s
C3188*: A2618s/ A2628/ R310s/ R320s/ R380s/ R520m/ T20s/ T28s/ T28s World/ T29s/ T39m
C3300: T65
C3331: J300/ J300i/ K300/ K300i/ P800/ P900/ S700i/ T68/ T68i/ T200/ T230/ T290i/ T300/ T310/ T610/

T630/ Z600

C3928: T66/ T600

C3959*: A3618/ J200i/ J210/ J210i/ K600/ K600i/ K608i/ K700i/ P910i/ R600/ T100/ T105/ V600i/ V600/
V800i/ Z200/ Z300i/ Z800/ Z800i/ Z1010

C4505: F500i/ K500i/ K508i

No charging available for this connector

01/10