

Acer adapter small pin 45W 19V2.37A (3.0 x 1.0mm) (24,95 EUR)



Locatie

Zuid-Holland, The Hague

<https://www.advertentiex.nl/x-1587256-z>



Weer moeiteloos jouw laptop opladen met een nieuwe laptop adapter. Adapters zetten de wisselstroom die uit jouw stopcontact komt om in gelijkstroom om je laptop te voeden. Een adapter kan het door slijtage helaas begeven. Hierdoor kun je vaak opeens jouw laptop niet meer gebruiken. Met een nieuwe adapter kun je weer snel aan de slag.

Wanneer jouw laptop adapter helaas stuk is, kun je deze laptop adapter uitstekend als vervanging gebruiken. Maar het is ook handig om een reserve adapter te hebben, voor het geval dat de originele defect gaat, of voor ergens anders dan thuis. Zo heb je altijd een extra oplader op het werk, op school of bij vrienden of familie bijvoorbeeld.

Acer Aspire A A315-22
Acer Aspire A A315-22-487B
Acer Aspire A A315-22-63D5
Acer Aspire A A315-22-670G
Acer Aspire A A315-55G
Acer Aspire A A315-55G-399C
Acer Aspire A A315-55G-59XE
Acer Aspire A A315-55G-71MP



Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentiaex.nl/x-1587>



Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentix.nl/x-1587256-z>



Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentix.nl/x-1587256-z>




Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentix.nl/x-1587256-z>

[illegible]

<https://www.advertentiaex.nl/x-1587256-z>



Acer adapter small pin 45W
19V 2.37A (30W)
6.5mm x 1.0mm

<https://www.advancesinartificialintelligence.nl/x-1587>




Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentia.nl/x-1587>
256-Z




Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentiax.nl/x-1587>
256-z



Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentex.nl/x-1587256-z>



Acer adapter small pin 45W
19V2.37A (3.0 x 1.0mm)

<https://www.advertentix.nl/x-1587256-z>

Acer Aspire A A514-52-58MS
Acer Aspire A A514-52-58NK
Acer Aspire A A514-52-7060
Acer Aspire A A515-54
Acer Aspire A A515-54-52VX
Acer Aspire A A515-54-5319
Acer Aspire A A515-54-53RR
Acer Aspire A A515-54-55F6
Acer Aspire A A515-54-58WW
Acer Aspire A A515-54-776L
Acer Aspire A A515-54-77GZ
Acer Aspire A A515-54-789H
Acer Aspire A A515-55-345C
Acer Aspire A A515-55-50K1
Acer Aspire A A515-55-513M
Acer Aspire A A515-55-576K
Acer Aspire A A515-55-588C
Acer Aspire One Cloudbook AO1-131
Acer Aspire One Cloudbook AO1-131M
Acer Aspire One Cloudbook AO1-132
Acer Aspire One Cloudbook AO1-431
Acer Aspire One Cloudbook AO1-431M
Acer Aspire R13
Acer Aspire Switch 11 SW5-171
Acer Aspire Switch 11 SW5-171-31U3
Acer Aspire Switch 11 SW5-171-325N
Acer Aspire Switch 11 SW5-171-332T
Acer Aspire Switch 11 SW5-171-3371
Acer Aspire Switch 11 SW5-171-34ZR
Acer Aspire Switch 11 SW5-171-368V
Acer Aspire Switch 11 SW5-171-36SV
Acer Aspire Switch 11 SW5-171-36T8
Acer Aspire Switch 11 SW5-171-377Z
Acer Aspire Switch 11 SW5-171-3867
Acer Aspire Switch 11 SW5-171-39AV
Acer Aspire Switch 11 SW5-171-39LB
Acer Aspire Switch 11 SW5-171-80KM
Acer Aspire Switch 11 SW5-171-86EE
Acer Aspire Switch 11 SW5-171-88JV
Acer Aspire Switch 11 SW5-171-89W0

Acer Aspire Switch 11 SW5-171-F34D
Acer Aspire Switch 11 SW5-171P-31HQ
Acer Aspire Switch 11 SW5-171P-36BN
Acer Aspire Switch 11 SW5-171P-82B3
Acer Aspire Switch 11 SW5-171P-87GQ
Acer Aspire Switch 11 SW5-171P-87VK
Acer Aspire Switch 11 SW5-173
Acer Aspire Switch 11 SW5-173-60MC
Acer Aspire Switch 11 SW5-173-60VD
Acer Aspire Switch 11 SW5-173-614T
Acer Aspire Switch 11 SW5-173-61V5
Acer Aspire Switch 11 SW5-173-62J8
Acer Aspire Switch 11 SW5-173-632W
Acer Aspire Switch 11 SW5-173-6337
Acer Aspire Switch 11 SW5-173-63DW
Acer Aspire Switch 11 SW5-173-63NV
Acer Aspire Switch 11 SW5-173-640L
Acer Aspire Switch 11 SW5-173-648Z
Acer Aspire Switch 11 SW5-173-64DH
Acer Aspire Switch 11 SW5-173-65R3
Acer Aspire Switch 11 SW5-173-668G
Acer Aspire Switch 11 SW5-173-66EG
Acer Aspire Switch 11 SW5-173-6742
Acer Aspire Switch 11 SW5-173-67WY
Acer Aspire Switch 11 SW5-173-69GL
Acer Aspire Switch 11 SW5-173-69U3
Acer Aspire Switch 11 SW5-173P
Acer Aspire Switch 12
Acer Aspire Switch 12 S SW7-272
Acer Aspire Switch 12 S SW7-272-M0JS
Acer Aspire Switch 12 S SW7-272-M51S
Acer Aspire Switch 12 S SW7-272-M5FE
Acer Aspire Switch 12 S SW7-272-MOIS
Acer Aspire Switch 12 S SW7-272P
Acer Aspire Switch 12 S SW7-272P-M8V4
Acer Aspire Switch 12 S SW7-272P-M9JP
Acer Aspire Switch 12 SW5-271
Acer Aspire Switch 12 SW5-271-60A4
Acer Aspire Switch 12 SW5-271-60QB
Acer Aspire Switch 12 SW5-271-61G9

Acer Aspire Switch 12 SW5-271-61X7
Acer Aspire Switch 12 SW5-271-61Y5
Acer Aspire Switch 12 SW5-271-61ZF
Acer Aspire Switch 12 SW5-271-621K
Acer Aspire Switch 12 SW5-271-62K0
Acer Aspire Switch 12 SW5-271-62X3
Acer Aspire Switch 12 SW5-271-63ST
Acer Aspire Switch 12 SW5-271-63V0
Acer Aspire Switch 12 SW5-271-643U
Acer Aspire Switch 12 SW5-271-64V2
Acer Aspire Switch 12 SW5-271-67SF
Acer Aspire Switch 12 SW5-271-68CX
Acer Aspire Switch 12 SW5-271-69SE
Acer Chromebook 11 C731
Acer Chromebook 11 C731T
Acer Chromebook 11 CB3-131
Acer Chromebook 11 CB3-132-C792
Acer Chromebook 11 CB311-7H
Acer Chromebook 11 CB311-7HT
Acer Chromebook 14 CB3-431-C5K7
Acer Chromebook 14 CB3-431-C705
Acer Chromebook 14 CB3-431-C73M
Acer Chromebook 15 CB3-532-C3MX
Acer Chromebook 15 CB3-532-C8E0
Acer Spin 1 SP111-32N
Acer Spin 1 SP111-34N
Acer Spin 1 SP111-34N-P765
Acer Spin 3 SP314-51
Acer Spin 3 SP314-51-35K4
Acer Spin 3 SP314-51-38U5
Acer Spin 3 SP314-51-503D
Acer Spin 3 SP314-51-P0AM
Acer Spin 3 SP314-52
Acer Spin 3 SP314-52-31FP
Acer Spin 3 SP314-52-33FP
Acer Spin 3 SP314-52-53SD
Acer Spin 3 SP314-52-54R2
Acer Spin 3 SP314-52-57S9
Acer Spin 3 SP314-52-599W
Acer Spin 3 SP314-53N-553L

Acer Spin 3 SP314-53N-575U
Acer Spin 5 Pro SP513-52NP
Acer Spin 5 SP513-52
Acer Spin 5 SP513-52N
Acer Spin 5 SP513-53N
Acer Swift 1 SF113-31
Acer Swift 1 SF114-31
Acer Swift 1 SF114-32
Acer Swift 1 SF114-32-C0Q9
Acer Swift 1 SF114-32-C4EY
Acer Swift 1 SF114-32-C7C0
Acer Swift 1 SF114-32-P4UL
Acer Swift 1 SF114-32-P5FF
Acer Swift 3 Pro SF313-51-58M9
Acer Swift 3 SF313-51
Acer Swift 3 SF314-41
Acer Swift 3 SF314-41-R2GP
Acer Swift 3 SF314-41-R70W
Acer Swift 3 SF314-51
Acer Swift 3 SF314-52
Acer Swift 3 SF314-53G
Acer Swift 3 SF314-54
Acer Swift 3 SF314-54-5069
Acer Swift 3 SF314-54-58Q8
Acer Swift 3 SF314-55
Acer Swift 3 SF314-56
Acer Swift 3 SF314-56-544M
Acer Swift 3 SF314-58
Acer Swift 3 SF314-58-319M
Acer Swift 3 SF314-58-32E9
Acer Swift 3 SF314-58-52WW
Acer Swift 3 SF314-58-58XS
Acer Swift 3 SF314-58-59KV
Acer Swift 3 SF314-58-73UP
Acer Swift 3 SF315-41
Acer Swift 3 SF315-51
Acer Swift 3 SF315-52
Acer Swift 5 SF514-51
Acer Swift 5 SF514-52
Acer Swift 5 SF514-52T

Acer Swift 5 SF514-52TP
Acer Swift 5 SF514-53T
Acer Swift 5 SF514-53T-59RQ
Acer Swift 5 SF514-53T-710Y
Acer Swift 5 SF515-51T
Acer Swift 5 SF515-51T-500N
Acer Swift 5 SF515-51T-513P
Acer Swift 5 SF515-51T-552D
Acer Switch 3 SW312-31
Acer Switch 3 SW312-31-C0FJ
Acer Switch 3 SW312-31-P64L
Acer Switch 3 SW312-31P
Acer Switch 5 SW512-52
Acer Switch 5 SW512-52P
Acer Switch 5 SW512-52P-54J6
Acer Travelmate B117-M-C1W5
Acer Travelmate B117-M-C268
Acer Travelmate B117-M-C2KX
Acer Travelmate B117-M-C2T9
Acer Travelmate B117-M-C4W4
Acer Travelmate B117-M-C578
Acer Travelmate B117-M-C6P3
Acer Travelmate B117-M-C98T
Acer Travelmate B117-M-C9VX
Acer Travelmate B117-M-P04U
Acer Travelmate B117-M-P089
Acer Travelmate B117-M-P0ST
Acer Travelmate B117-M-P12K
Acer Travelmate B117-M-P16Q
Acer Travelmate B117-M-P24P
Acer Travelmate B117-M-P2QC
Acer Travelmate B117-M-P3GQ
Acer Travelmate B117-M-P4VH
Acer Travelmate B117-M-P5M3
Acer Travelmate B117-M-P64N
Acer Travelmate B117-M-P6FJ
Acer Travelmate B117-M-P6PA
Acer Travelmate B117-M-P72Q
Acer Travelmate B117-M-P7VH
Acer Travelmate B117-M-P8E8

Acer Travelmate B117-M-P8JR
Acer Travelmate B117-M-P994
Acer Travelmate B117-M-P9C2
Acer Travelmate B117-M-P9LM
Acer Travelmate B117-MP-C0DK
Acer Travelmate B117-MP-C19R
Acer Travelmate B117-MP-C2G3
Acer Travelmate B117-MP-C877
Acer Travelmate B117-MP-C90Q
Acer Travelmate B117-MP-C9GC
Acer Travelmate B118-G2-RN-P31P
Acer Travelmate B118-G2-RN-P42M
Acer Travelmate B118-G2-RN-P5WE
Acer Travelmate B118-M
Acer Travelmate B118-R-C65T
Acer Travelmate B118-R-C9Y8
Acer Travelmate B118-R-P27R
Acer Travelmate B118-R-P676
Acer Travelmate B118-R-P8NM
Acer Travelmate P2 TMP214-5-59R2
Acer Travelmate P2 TMP215-52-516R
Acer Travelmate P2 TMP215-52-78JJ
Acer Travelmate P6 TMP614-51T-73CS
Acer Travelmate Spin B118-RN B118-RN-C2Z9
Acer Travelmate Spin B118-RN B118-RN-C42Z
Acer Travelmate Spin B118-RN B118-RN-C53N
Acer Travelmate Spin B118-RN B118-RN-C6FD
Acer Travelmate Spin B118-RN B118-RN-C6WX
Acer Travelmate Spin B118-RN B118-RN-P10F
Acer Travelmate Spin B118-RN B118-RN-P4J9
Acer Travelmate Spin B118-RN B118-RN-P6BE
Acer Travelmate Spin B118-RN B118-RN-P6NE
Acer Travelmate Spin B118-RN B118-RN-P7PC
Acer Travelmate Spin B118-RN B118-RN-P7UK
Acer Travelmate Spin B118-RN B118-RN-P7XQ
Acer Travelmate Spin B118-RN B118-RN-R6P1
Acer Travelmate Spin B118-RN B118-RN-R6P7
Acer Travelmate Spin B1 TMB118-G2-RN
Acer Travelmate Spin B1 TMB118-G2-RN-C4CE
Acer Travelmate Spin B1 TMB118-G2-RN-P1C2

Acer Travelmate Spin B1 TMB118-G2-RN-P42M
Acer Travelmate Spin B1 TMB118-G2-RN-P5CU
Acer Travelmate Spin B1 TMB118-G2-RN-P7ED
Acer Travelmate X5 TMX514-51-550R
Acer Travelmate X5 TMX514-51-581T
Acer Travelmate X5 TMX514-51-72P6
Acer Travelmate X5 TMX514-51-74WH
Acer Travelmate X5 TMX514-51T-59YG
Acer Travelmate X514-51-511Q
Acer Travelmate X514-51-58D4
Acer Travelmate X514-51T
Acer Travelmate X514-51T-51T5
Acer Travelmate X514-51T-57Q4

Originele adapter onderdeelnummers

KP.06501.010 Acer
KP.06503.002 Acer
KP.06503.004 Acer
KP.06503.005 Acer
KP.0650H.006
PA-1650-80 Acer
W16-065N4A Acer

Ean: 7445908090051
SKU: 7445908090051

Supersnelle levering, binnen 24 uur in huis!
Niet goed = Geld terug
14 dagen bedenktijd
Afhalen aan onze balie

Afhaal adres:
SaleMedia.nl
Waldorpstraat 347
2521 CJ Den Haag
070-2629111

Openingstijden:

Maandag: 10:00-18:00
Dinsdag: 10:00-18:00
Woensdag: 10:00-18:00
Donderdag: 10:00-18:00
Vrijdag: 10:00-18:00
Zaterdag: Gesloten
Zondag: Gesloten

Klik op onderstaande product link voor meer informatie over het product en om direct te bestellen. [Website](#) klik hier voor bestellen en/of