

NTK OZA384-E32 O2 sensor Lexus Toyota (49, EUR)




Locatie

Noord-Brabant, Cuijk

<https://www.advertentia.nl/x-1800798-z>

34



Lengte 392mm; 4 leidingen * LEXUSES Saloon (F1, F2)198912 - 199712 * TOYOTACARINA Mk II Saloon (_T17_)198712 - 199306 * TOYOTACARINA Mk II (_T17_)198712 - 199306 * TOYOTACARINA Mk II Estate (_T17_)198712 - 199204 * TOYOTACAMRY Saloon (_V2_)198610 - 199106 * TOYOTASCEPTER (_CV1_, _XV1_, _V1_)199106 - 199709 * TOYOTACAMRY Station Wagon (_V2_)198611 - 199106 * TOYOTASCEPTER Estate (_XV1_, _CV1_, _V10)199106 - 199708 * TOYOTACELICA Hatchback (T16)198508 - 199008 * TOYOTACELICA Coupe (T16F)198701 - 199008 * TOYOTAMR 2 I (_W1_)198411 - 199006 * TOYOTACELICA Coupe (_T18_)198910 - 199403 * TOYOTAHIACE III Wagon (H50)198908 - 199508 * TOYOTAESTIMA (TCR2_, TCR1_)199005 - 200008 * TOYOTACARINA E Saloon (_T19_)199204 - 199709 * TOYOTACARINA E Hatchback (_T19_)199204 - 199709 * TOYOTACARINA E Sportswagon (_T19_)199301 - 199709 * TOYOTACELICA (_T20_)199311 - 199911 * TOYOTALAND CRUISER (_J8_)199001 - 199802 * TOYOTASURF (_N130)198708 - 199603 * TOYOTATACOMA II Pickup (_N_)198211 - 200507 * TOYOTAHIACE III Box (H50)198908 - 199508 * TOYOTALAND CRUISER - BUNDERA (_J7_)198403 - / * TOYOTATARAGO Bus (_R2_, 31)198211 - 199010 * TOYOTAHILUX SURF Closed Off-Road Vehicle198809 - / * TOYOTAHIACE IV Wagon (H100)199508 - 200609 * TOYOTACORONA Saloon198711 - 199309 * TOYOTAMR 2 II (_W2_)198912 - 200005

ManufacturerNumber	Description
AMC56041344AB	()Lambda SensorAMC56041344AC
	()Lambda SensorASHIKA43-M06
	()Lambda SensorASHIKA43-MI07
	()Lambda SensorASHIKA43-T05
	()Lambda SensorASHIKA43-Y09
	()Lambda SensorASSO10.7008
	()End SilencerBLUE PRINTADC47026
	()Lambda SensorBLUE PRINTADG07045C
	()Lambda SensorBLUE PRINTADH27036
	()Lambda SensorBLUE PRINTADN17022
	()Lambda SensorBOSCH0 258 003 152
	()Lambda SensorBOSCH0 258



NTK OZA384-E32 O2 sensor
Lexus Toyota



NTK OZA384-E32 O2 sensor
Lexus Toyota
<https://www.advertentie.nl/x-1800>
798-z




NTK OZA384-E32 O2 sensor
Lexus Toyota
<https://www.advertentielex.nl/x-1800>
798-z




NTK OZA384-E32 O2 sensor
Lexus Toyota
<https://www.advertentiaex.nl/x-1800>
798-z




003 544 (Lar SensorBOSC
003 759 (Lar SensorBOSC
005 001 (Lar SensorBOSC




<https://www.adalightptx.com/n/x-1800>
 258 003 713
 a SensorBOS
 258 003 870
 a SensorBOS
 258 005 083
 Toyota
 O2 sensor



2500003556	bd SensorBO	02 sensor
2500003779	bd SensorBO	02 sensor
2500005055	bd SensorBO	02 sensor



hbd SensorBO
H0 258 003 71
hbd SensorBO
H0 258 003 89
hbd SensorBO
H0 258 005 11



H0 258 003 64	Lexus	Toyota
Lambda Sensor		
H0 258 003 85		
Lambda Sensor		
H0 258 005 07		
Lambda Sensor		

[illegible]

005 115 ()Lambda SensorBOSCH0 258 005 134 ()Lambda SensorBOSCH0 258 005 135 ()Lambda
SensorBOSCH0 258 005 136 ()Lambda SensorBOSCH0 258 005 162 ()Lambda SensorBOSCH0 258
005 163 ()Lambda SensorBOSCH0 258 005 191 ()Lambda SensorBOSCH0 258 005 240 ()Lambda
SensorBOSCH0 258 005 242 ()Lambda SensorBOSCH0 258 005 249 ()Lambda SensorBOSCH0 258
005 251 ()Lambda SensorBOSCH0 258 005 253 ()Lambda SensorBOSCH0 258 005 254 ()Lambda
SensorBOSCH0 258 005 255 ()Lambda SensorBOSCH0 258 005 256 ()Lambda SensorBOSCH0 258
005 261 ()Lambda SensorBOSCH0 258 005 263 ()Lambda SensorBOSCH0 258 005 266 ()Lambda
SensorBOSCH0 258 005 293 ()Lambda SensorBOSCH0 258 005 295 ()Lambda SensorBOSCH0 258
005 705 ()Lambda SensorBOSCH0 258 005 708 ()Lambda SensorBOSCH0 258 005 710 ()Lambda
SensorBOSCH0 258 005 716 ()Lambda SensorBOSCH0 258 005 717 ()Lambda SensorBOSCH0 258
005 718 ()Lambda SensorBOSCH0 258 005 722 ()Lambda SensorBOSCH0 258 005 728 ()Lambda
Sensor; Lambda SensorBOSCH0 258 005 736 ()Lambda SensorBOSCH0 258 986 504 ()Lambda
Sensor; Lambda SensorBOSCH0 258 986 506 ()Lambda Sensor; Lambda SensorBOSCH0 258 986 507
()Lambda SensorBOSCHF 00H L00 048 ()Lambda SensorBOSCHF 00H L00 050 ()Lambda
SensorBOSCHF 00H L00 063 ()Lambda SensorBOSCHF 00H L00 080 ()Lambda SensorBOSCHF 00H
L00 081 ()Lambda SensorCALORSTAT BY VERNETLS140246 ()Lambda SensorCALORSTAT BY
VERNETLS140247 ()Lambda SensorCALORSTAT BY VERNETLS140248 ()Lambda
SensorCALORSTAT BY VERNETLS140295 ()Lambda SensorCALORSTAT BY VERNETLS140306
()Lambda SensorCALORSTAT BY VERNETLS140307 ()Lambda SensorCALORSTAT BY
VERNETLS140308 ()Lambda SensorCEVAM0133 ()Suspension Sphere, pneumatic
suspensionCHRYSLER04605 270 ()Lambda SensorCHRYSLER04606 037 ()Lambda
SensorCHRYSLER04606 061 ()Lambda SensorCHRYSLER04606 067 ()Lambda
SensorCHRYSLER04606 069 ()Lambda SensorCHRYSLER04606 075 ()Lambda
SensorCHRYSLER04606 090 ()Lambda SensorCHRYSLER04606 091 ()Lambda
SensorCHRYSLER04606 140 ()Lambda SensorCHRYSLER04671 066 ()Lambda
SensorCHRYSLER04686 933 ()Lambda SensorCHRYSLER0M04606037 ()Lambda
SensorCHRYSLER4605270 ()Lambda SensorCHRYSLER4606 037 ()Lambda SensorCHRYSLER4606
061 ()Lambda SensorCHRYSLER4606067 ()Lambda SensorCHRYSLER4606 069 ()Lambda
SensorCHRYSLER4606075 ()Lambda SensorCHRYSLER4606090 ()Lambda
SensorCHRYSLER4606091 ()Lambda SensorCHRYSLER4606 140 ()Lambda SensorCHRYSLER4671
066 ()Lambda SensorCHRYSLER4686 933 ()Lambda SensorCHRYSLER56005 925 ()Lambda
SensorCHRYSLER56026 827 ()Lambda SensorCHRYSLER56027 902 ()Lambda
SensorCHRYSLER56028 301 ()Lambda SensorCHRYSLER56028 603 ()Lambda
SensorCHRYSLER56041213AF ()Lambda SensorCHRYSLER86028 301 ()Lambda
SensorCITROEN/PEUGEOT96369688 ()Lambda SensorDENSODOX-0101 ()Lambda
SensorDENSODOX-0216 ()Lambda SensorDODGE04606061 ()Lambda SensorDODGE04606069
()Lambda SensorDODGE4605270 ()Lambda SensorDODGE4606037 ()Lambda SensorDODGE4606061
()Lambda SensorDODGE4606067 ()Lambda SensorDODGE4606 069 ()Lambda SensorDODGE4606075
()Lambda SensorDODGE4606090 ()Lambda SensorDODGE4606091 ()Lambda SensorDODGE4606140
()Lambda SensorDODGE4671066 ()Lambda SensorDODGE4686933 ()Lambda

SensorDODGE56005925 ()Lambda SensorDODGE56026827 ()Lambda SensorDODGE56027902
()Lambda SensorDODGE56028301 ()Lambda SensorDODGE56028603 ()Lambda SensorDODGE56041
213AF ()Lambda SensorDODGE86028301 ()Lambda SensorFACET10.7372 ()Lambda SensorFAE77331
()Lambda SensorFRECCIA6380 ()Inlet ValveHERTH+BUSS JAKOPARTSJ1472003 ()Lambda
SensorHOFFER7481022 ()Lambda SensorHOFFER7481052 ()Lambda SensorHOFFER7481059
()Lambda SensorHOFFER7481074 ()Lambda SensorJAPANPARTSOO-T05 ()Lambda
SensorJAPKO3T05 ()Lambda SensorJAPONIAJ1474001HB () JEEP4605270 ()Lambda
SensorJEEP4606037 ()Lambda SensorJEEP4606067 ()Lambda SensorJEEP4606069 ()Lambda
SensorJEEP4606075 ()Lambda SensorJEEP4606090 ()Lambda SensorJEEP4606091 ()Lambda
SensorJEEP4606140 ()Lambda SensorJEEP4671066 ()Lambda SensorJEEP4686933 ()Lambda
SensorJEEP56005 925 ()Lambda SensorJEEP56026827 ()Lambda SensorJEEP56027 902 ()Lambda
SensorJEEP56028301 ()Lambda SensorJEEP56028 603 ()Lambda SensorJEEP56041 213AF ()Lambda
SensorJEEP86028301 ()Lambda SensorLEXUS89465-28070 ()Lambda SensorMAGNAFLOW77004
()Catalyst ConverterMAGNETI MARELLI460000133010 ()Lambda SensorMAGNETI
MARELLI461912164110 ()Lambda SensorMEAT & DORIA81022 ()Lambda SensorMEAT &
DORIA81052 ()Lambda SensorMEAT & DORIA81059 ()Lambda SensorMEAT & DORIA81074 ()Lambda
SensorMOBILETRON71E0008WOYO ()PROBELAMBDAMULTIPLE-PURPOSEMTE-
THOMSON7835.45.063 ()Lambda SensorMTE-THOMSON7839.45.031 ()Lambda SensorMTE-
THOMSON7840.40.042 ()Lambda SensorMTE-THOMSON7840.40.056 ()Lambda SensorNGK0133
()Lambda SensorNGK6380 ()Lambda SensorNGKOZA28C36380 ()Lambda probeNGKOZA384E320133
()Lambda probeNISSAN226A015700 ()Lambda SensorNISSAN226A015705 ()Lambda
SensorSPIDAN26172 ()Bellow, drive shaftSWAG50 92 1383 ()Lambda SensorTOPRAN721 860
()Lambda SensorTOPRAN721 861 ()Lambda SensorTOYOTA8946528070 ()Lambda
SensorTOYOTA8946535220 ()Lambda SensorTOYOTA8946535240 ()Lambda
SensorTOYOTA8946560010 ()Lambda SensorVEMOV70-76-0002 ()Lambda SensorWALKER21383
()End SilencerWALKER PRODUCTS250-24002 ()Lambda SensorWALKER PRODUCTS250-24003
()Lambda SensorWALKER PRODUCTS250-24052 ()Lambda Sensor

Websitewww.chargertech.nl/outlet/sensoren/ntk-oza384-e32-o2-sensor-lexus-toyota.html?channable=41
71d0696400343638307e&utm_campaign=marktplaats&utm_content=&utm_source=marktplaats.nl&utm_
medium=cpc&utm_medium=cpc