
which results in a large de-power range, amazing progressive handling, boost for jumping and drift in the waves. The V2 design features our new strut construction that provides enhanced support to the canopy and improves stability at low angles of attack. The Leading Edge is now tapered at the tip, which helps to reduce tip bounce. Together, the result is a much smoother ride and a more solid bar feeling in strong and gusty conditions.

FREERIDE: For Freeriders the Enduro excels no matter what board you choose to ride. Whether on a twin tip, surfboard or foil board the smooth power delivery, refined predictable handling and excellent de-power allows you to relax and enjoy the ride.

WAVE RIDING: In the Waves, the handling, depower and drift opens up a world of opportunity. For surf freestyle the progressive handling with smooth lift make spinning and air tricks easy to learn and land. The Enduro is not as dedicated to waves as the Reo, but it still delivers solid wave riding performance.

FREESTYLE: The Enduro makes freestyle progress fun and easy from your first unhooked moves, kite loops and right up to advanced unhooked riding. The Enduro delivers accessible pop and drop making learning technical moves and handle passes easier, without needing to be as aggressive in your riding compared with a C-kite such as the C4. The Enduro features multiple back line adjustments to customize steering pressure and turn speed. Combined with our Variable Bridle Geometry, this allows you to ultimately customize the feeling and performance of your kite.

VARIABLE BRIDLE GEOMETRY

Quick and easy to change with no extra lines to add or remove.

FREERIDE: The Freeride setting offers the ideal balance in performance and feeling for all-round riding in any conditions. The Freeride setting is the middle knot on the VBG Pigtales (factory setting).

WAVE: The Wave setting decreases the bar pressure, and increases steering reactivity in all states of power and de-power - it is easier to turn the kite while de-powered when riding a wave. The Wave setting is the upper knot on the VBG Pigtales.

FREESTYLE: The Freestyle setting increases sheeting bar pressure, increases power in the kite loop and increases pop for unhooked tricks. If you prefer a heavier and direct feel this could be the setting for you. The Freestyle setting is the lower knot on the VBG.